February 11, 2026

EA660 (3rd Gen)

HW

In EA660, Status bar show "Backyp battery warning. Backup battery voltage is low ……"?

Main battery is removed for long time to cause backup battery low. Please insert main battery. It will take 3 hours to full charge backup battery.

OS

Does EA660 WLAN support GPS?

EA660 WLAN does not include GPS.

Can EA660 /PA768/RT112 support VoNR?

Yes, EA660 /PA768/RT112 can support VoNR.

Enroll EA660 into Intune using AE QR Code Via Intune provisioned WiFi profile's. The WiFi profiles were created, but when select the WiFi it asked to enter passkey?

It happen on MR1 and can be solved by MR3 OS

EA660 cannot connect to Android Auto?

Problem solved on MR3 OS

unitech electronics co., ltd.
5F No. 136, Lane 235, Pao-Chiao Rd., Hsin-Tien City, Taipei Hsien, Taiwan 231, R.O.C.
• Tel: +886-2-8912-1122 • Fax: +886-2-8912-1391 • Website: www.ute.com

In EA660,What is VoNR?

Voice over New Radio (VoNR) provides enhanced voice quality, with higher-definition audio and reduced background noise. VoNR also enables lower latency, ensuring near-real-time communication.

Does EA660 support VoNR?

Yes, EA660 supports VoNR

Software

In EA660, Using Ivanti Kiosk, HDMI 2nd screen become black?

Ivanti Kiosk working after disabled kiosk option [Enable Lock Task mode].

USS

Can EA660 read reverse DataMatrix barcode ?

Yes, setup USS --> Symbology Settings --> Data Matrix --> Data Matrix Inverse --> Inverse Only or Inverse Autodetect